


# Closed-Loop Swash Plate Type Axial Piston Pump K8V series



### CONTENTS

I. Applications / Product Usage	2
II. Safety Precautions	3
III. Handling Precautions	
1. Operating Fluid and Temperature Range	4
1) Operating Fluid	
2) Viscosity and Temperature Range	
2. Filtration and Contamination Control	
1) Filtration of Working Oil	
2) Suggested Acceptable Cleanliness Level	
3. Drive Shaft Coupling	5
4. Oil Filling and Air Bleeding	
1) Pump Case Filling	
2) Air Bleeding	
3) Long Term Storage	
5. Drain Piping	6
<ul><li>1) Installation of Drain Line</li><li>2) Size of Drain Hose • Drain Pipe</li></ul>	7
6. Shaft Loading and Bearing Life	/
IV. Conversion Factors, Formula and Definition	8
The conversion ractors, rormola and bermitton	O
• K8V Series Closed-Loop Variable Displacement Type A	Axial Piston Pumn
Specifications, General Descriptions, and Features	10
1. Ordering Code	10
1-1. Pump Options	11
1-2. Regulator Options	12
2. Technical Information	
2-1. Specifications	13
<ul> <li>Relief Valve</li> </ul>	14
<ul> <li>Pressure Cut-off</li> </ul>	
Charge Pump	15
2-2. Functional Description of Regulator	
<ul> <li>Electric Proportional Control</li> </ul>	17
<ul> <li>Hydraulic Pilot Displacement Control</li> </ul>	18
<ul> <li>Mechanical Stroke Limiter</li> </ul>	19
<ul> <li>Stroking Speed Control Orifice</li> </ul>	
3. Dimensions	
3-1. Installation Dimensions	
• K8V90	20
K8V90 Port Details	21
K8V90 Through Drive Options     K8V90 Through Drive Options	22
• K8V125	25
K8V125 Port Details     K8V125 Through Prive Options	27
K8V125 Through Drive Options     Application of Application Pumps	28
3-2. Installation of Auxiliary Pumps	31
K8V Series Inquiry Form	32

### I. Applications / Product Usage

### The following must be taken into consideration before use.

- 1. The operating condition of the products shown in this catalog varies depending upon each application. Therefore, the product suitability must be judged by the designer of the hydraulic system and/or the person who finalizes the technical specifications of the machine after analysis and testing. The product specification shall be determined based on the latest catalog and technical documents. The system must be designed taking into account the possibility of machine failure to ensure that all safety, warning, and application requirements are met.
- For the proper use of the products, descriptions given in the SAFETY PRECAUTIONS must be observed.
- The technical information in this catalog represents typical characteristics and performance of the products as of the published date.

- 4. If the products are intended for use in the following, please consult with Kawasaki in advance.
  - (1) Use the product under the operating conditions or environments other than those described in the technical documents.
  - (2) Use the product in the nuclear sector, aviation sector, medical sector, and/or food sector.
  - (3) Use the product in applications which may cause substantial harm to others and their property, and especially in applications where ensuring safety is a requirement.
- 5. The information described in this catalog is subject to change without notice. For the latest information, please contact Kawasaki.

### II. Safety Precautions

Before using the product, you MUST read this catalog and MUST fully understand how to use the product. To use the product safely, you MUST carefully read all Warnings and Cautions in this catalog.

#### 1. Cautions related to operation



- Use personal protective equipment to prevent injury when the product is in operation.



- Some components are heavy. Handle the product carefully not to hurt your hands and lower back.



 Do not step on, hit or drop, or apply strong force to the product, as these actions may cause operation failure, product damage, or oil leakage.



- Wipe off any oil on the product or the floor completely, as oil can create slippery conditions that may cause drop of the product and personal injury.

### 2. Warnings and Cautions related to installation and removal of the product



- Installation, removal, piping, and wiring must be done by a qualified technician.



- Make sure that the hydraulic power unit is turned off and that the electric motor or engine has completely stopped before starting installation or removal. You must also check that the system pressure has dropped to zero.



- Make sure that the power source is turned off before installing electric components to reduce the risk of electric shock.



- Clean the threads and the mounting surface to prevent damage or oil leakage. Inadequate cleaning may cause insufficient torque and broken seals.



- Use the designated bolts and fasten them with prescribed torque when installing the product. Use of undesignated bolts, and excessive or insufficient tightening torque may induce operation failure, damage, or oil leakage.

### 3. Warnings and Cautions for operation



- Always equip the product with explosion or ignition protection if it is used in potentially explosive or combustible atmospheres.



- Shield rotary parts, such as the motor and pump shaft, to avoid injury.



- Stop operation immediately, and take proper measures when the abnormality such as unusual noise, oil leakage, and smoke is found. Continuing operation under such condition may bring about damage, a fire hazard, or injury.



- Make sure that all pipes, hoses, and connecting points with pipes or hoses, are correctly connected and tightened before starting operation.



- Use the product under the operating conditions and limitations described in the catalog, drawings, and specification sheets.



- Do not touch the product in operation, to reduce the risk of skin burn.



- Use the proper hydraulic oil and maintain the filtration at the recommended level to prevent premature wear and damage.

#### 4. Cautions related to maintenance



- Never modify the product without approval from Kawasaki.



- Disassembly of the product may void the warranty.



- Keep the product clean and dry when storing or transporting.



- The seals may need to be replaced if the product has been stored for an extended period of time.

### III. Handling Precautions

### 1. Operating Fluid and Temperature Range


### 1) Operating Fluid

Values shown in this catalog are based upon using mineral based anti-wear hydraulic fluid. To ensure optimal performance use of mineral based anti-wear hydraulic fluid is recommended.

### 2) Viscosity and Temperature Range

To minimize both oil and seal deterioration, a maximum operating temperature of 140°F (60°C) should be considered. Additionally it must be noted that when operating at low temperatures 59~68°F (15~20°C) some delay in response of the regulator may occur. At such low temperatures it is suggested that a warm up cycle is introduced until an operating temperature of 68°F (20°C) is achieved.

	Suitable range for Normal operation	Allowable range
Viscosity [mm²/s(cSt)]	10 ~ 200	10 ~ 1,000
Fluid Temperature [°F (°C)]	-4 ~ +203 (−20 ~ +95)	



### 2. Filtration and Contamination Control

#### 1) Filtration

The most important means to prevent premature damage to the pump and associated equipment and to extend its working life, is to ensure that hydraulic fluid contamination control of the system is working effectively.

This begins by ensuring that at the time of installation that all piping, tanks etc. are rigorously cleaned in a sanitary way. Flushing should be provided using an off line filtration system and after flushing the filter elements should be replaced.


### 2) Suggested Acceptable Cleanliness Level

The relationship between contamination level and pump life is very difficult to predict as it depends on the type and nature of the contaminant present in the system. Sand or Silica in particular, due to its abrasive nature, does significantly reduce the expected life of a pump. Based on the precondition that there is no significant presence of Silica type substances then a minimum Cleanliness level of -/18/15 ISO 4406 or SAE AS 4059E Table 1 Class 9 (NAS 1638 Class 9).

### 3. Drive Shaft Coupling

Alignment between the prime mover and the pump shaft should be within a tolerated margin, that is, parallel misalignment within 0.05mm TIR\* and angular misalignment within 0.2°TIR\*. In case the pump is directly coupled to the engine flywheel, use a flexible coupling.

\*TIR = Total Indicator Reading



### 4. Oil Filling and Air Bleeding

### 1) Pump Case Filling

Be sure to fill the pump casing with oil through the drain port, filling only the suction line with oil is in-sufficient. The pump contains bearings and high-speed sliding parts including pistons with shoes and a spherical bush that need to be continuously lubricated. Part seizure or total premature failure will occur very quickly if this procedure is not rigidly followed.

### 2) Air Bleeding

Run the pump unloaded for a period to ensure that all residual air within the system is released.


#### 3) Long Term Storage

It is undesirable to leave the pump out of use for a long period e.g. a year or more. In such a situation it is recommended that the pump is run for a short period on a more frequent basis even if it is just unloaded. With regard to a pump held in storage then rotating the shaft on a frequent basis is sufficient. If the pump is left out for more than the suggested time it will require a service inspection.

### 5. Drain Piping

### 1) Installation of Drain Line


It is the preferred option to mount the pump with the case drain piping initially rising above the pump before continuing to the tank. Do not connect the drain line to the inlet line.



#### **Cautions**


- A) Inlet and drain pipes must be immersed by 7.8" (200 mm) minimum from the lowest level under operating conditions.
- **B)** Height from the oil level to the centre of the shaft must be within 40" (1 meter) maximum.
- **C)** The oil in the pump case must be refilled when the pump has not been operated for one month or longer.

The uppermost drain port should be used and the drain piping must be larger in size than the drain port to minimize pressure in the pump case. The pump case pressure must not exceed 29psi (2 bar) as shown in the illustration below. (Peak pressure must never exceed 87psi (6 bar).)



### Mounting the Pump Above the Tank

Suction line



### **III. Handling Precautions**

### 2) Size of Drain Hose or Drain Pipe

The internal bore size of the drain hose or drain pipe must be larger than that of the drain port. Arrange the drain line as short as possible.

### 6. Shaft Loading and Bearing Life

Although K8V pumps are equipped with bearings that can accept some external radial forces, exertion of external radial loads will affect bearing life. Depending on the load magnitude, the load position, and the load orientation, bearing life may be influenced and reduced.

Consult with Kawasaki for further details.

## IV. Conversion Factors, Formula and Definition

### • Conversion Factors

	Formula	Note
Displacement	$1 \text{ cm}^3 = 0.061 \text{ in}^3$	
Pressure	sure 1 MPa = 145 psi	
Flow	1 L/min = 0.264 gpm	US gallon
Torque	1 Nm = 0.74 lb ft	
Power	1 kW = 1.341 hp	
Weight	1 kg = 2.205 lbs	

### • Formula

	Metric system		Imperial system	
Output flow	$Q = q \times N \times n_v / 1000$	L/min	$Q = q \times N \times n_v / 231$	gal/min
Input torque	$T = q \times \Delta P / 2\pi / n_m$	Nm	$T = q \times \Delta P / 24\pi / n_m$	lbf-ft
Input power	$L = T \times N / 9550 = Q \times \Delta P / 60 / n_t$	kW	L = T x N / 5252 = Q x ΔP / 1714 / n <sub>t</sub>	hp

### • Definition


q	=	Pump displacement / rev.	cm³ (in³)
L	=	Input power	kW (hp)
N	=	Speed	min <sup>-1</sup> (rpm)
N <sub>max</sub>	=	Maximum speed at maximum displacement	min <sup>-1</sup> (rpm)
ΔΡ	=	P <sub>high</sub> - P <sub>low</sub> (Differential pressure)	MPa (psi)
P <sub>high</sub>	=	High pressure	MPa (psi)
P <sub>low</sub>	=	Low pressure	MPa (psi)
Prated	=	Rated pressure	MPa (psi)
P <sub>peak</sub>	=	Peak pressure	MPa (psi)
Pc	=	charge pressure	MPa (psi)
Т	=	Input torque	Nm (lbf-ft)
T <sub>max</sub>	=	Maximum input torque	Nm (lbf-ft)
n <sub>v</sub>	=	Pump volumetric efficiency	
$n_{\rm m}$	=	Pump mechanical efficiency	
$n_{\rm t}$	=	Pump total efficiency	

### MEMO

 •••••
•••••
•••••
 •••••

## **K8V Series**

## Closed-Loop Variable Displacement Type Axial Piston Pump



### Specifications

Size: 71\*, 90, 125

Rated Pressure: 5800 psi (400 bar) Peak Pressure: 6525 psi (450 bar)

### General Descriptions

The K8V series are variable displacement axial piston pumps for closed loop systems, with superior overall efficiency, stability, and control characteristics.

The K8V pumps are suitable for a wide range of applications, including industrial vehicles such as construction machinery, agricultural equipment with hydrostatic drive systems, and other closed loop applications. Also, this pump can be used in combination with M7V series motors for high pressure closed loop applications.

The K8V series with a range in pump size from 71cc & 125cc displacement and are equipped with electric or hydraulic pilot displacement control. The K8V series pumps, having the integrated components required for a closed system, such as a charge pump, high and low pressure relief valves, and a cut-off valve, enable a compact closed loop system.

### Features


- Swash plate type, variable displacement axial piston pump for closed-loop system
- High overall efficiency
- Suitable for wide range of applications
- Precise flow control
- High stability
- Excellent reliability
- Various integrated valves
- Bypass function for emergency towing

(\*) means under development

## 1 Ordering Code

### 1-1 Pump Options


Please fill the Inquiry Form on page 32 and 33 in order to specify the requirement.



1

### 1-2 Regulator Options

Please fill the Inquiry Form on page 32 and 33 in order to specify the requirement.



: Available: Under development: Not available

## 2 Technical Information

### 2-1 Specifications

Size			90	125
Displacement	Main pump	in³ (cm³)	5.5 (90)	8.1 (130)
Displacement	Charge pump	in³ (cm³)	1.2 (20)	1.7 (28)
Droccuro main	Rated	psi (bar)	5800 (400)	
Pressure, main	Peak	psi (bar)	6525	(450)
Pressure, charge	Rated	psi (bar)	363	(25)
Fressure, charge	Peak	psi (bar)	580	(40)
Allowable case pressure		psi (bar)	29 (2.0) continuo	us / 87 (6.0) peak
	Rated*1	min <sup>-1</sup>	3,050	2,850
Speed	Maximum <sup>*2</sup> (intermittent)	min <sup>-1</sup>	3,800	3,450
	Minimum	min <sup>-1</sup>	500	500
Case volume		gal (L)	0.8 (3.0)	1.1 (4.0)
Temperature range			-20 ~ +95 (case drain: 115 maximum, intermittent)	
Viscosity range		cSt	10 ~ 1,000	
Maximum contamination lev	vel		ISO 4406	5 -/18/15
		SAE A	90 (123)	90 (123)
		SAE B	291 (395)	291 (395)
Allowable through drive torque   Ib-ft (Nm)		SAE BB	424 (575)	472 (640)
		SAE C	424 (575)	535 (725)
		SAE CC	424 (575)	612 (830)
		SAE D	424 (575)	612 (830)
Mass	Mass lbs (kg)			210 (95)

<sup>\*1:</sup> maximum allowable speed for continuous operation.

#### Note:

Operation above the maximum values or below the minimum values may result in a loss of function, a reduced service life or the destruction of the pump.

### Allowable Maximum Input Torque

	SAE D (Spline type D1)	SAE F (Spline type D2)
Spline Specification	13T DP=8/16	15T DP=8/16
Allowable Maximum Input Torque   Ib-ft (Nm)	1084 (1,470)	1663 (2,255)
Pump Size	K8V90/125	K8V125 (Combination pump)

Input spline specification is based on SAE J744.

Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit.

Two options of mounting flange and shaft, D1 and D2, are available for K8V125 pumps.

In case of a combination pump of K8V125 which requires higher input torque than 1084 lb-ft (1470 Nm), D2 option must be used.

The shaft surface will have a finite life due to wear unless adequate lubrication is provided.

<sup>\*2:</sup> maximum allowable speed for limited operating period and duty. Exceeding this value will result in a reduced service life or the destruction of the pump.

### 2-1 Specifications

### Relief Valve

### 1. High pressure relief valve

High pressure relief valves (two valves) are equipped to protect the pump from being overloaded.

The high pressure relief valves act to protect the pump from pressure spikes in dynamic control situations and are not equipped for continuous operation.

The settings of the high pressure relief valves are shown in the table below.

#### **Pressure Settings**

Code[15]	Pressure Setting (MPa)		
А	4350 (300)		
В	5075 (350)		
С	5800 (400)		
D	6525 (450)		
S	Customized pressure setting for a special case Please contact Kawasaki.		

#### Note:


The allowable setting range of the high pressure relief valve is from 4350psi (300 bar) to 6525psi (450 bar), and the customized pressure must be set within this range. For a customized pressure setting contact Kawasaki with the required pressure setting value. The pressure of the high pressure relief valve is factory preset at 5800psi (400 bar), if not specified.

#### 2. Low pressure relief valve

The Low pressure relief valve is equipped to control the pressure for charge line and servo line.

The pressure setting of an integrated low pressure relief valve is preset at 363psi (25 bar) at the factory.

Do not adjust the pressure of the low pressure relief valve, as it may reduce the controllability of the pump.



**High Pressure Relief Valve Setting Diagram** 

### Pressure Cut-off

Pressure cut-off is the function which adjusts the pump displacement to the neutral position when the pressure reaches its pressure setting.

The pressure cut-off is set lower than high pressure relief valve setting, so that the maximum pump pressure is controlled by the pressure cut-off valve, whereas the high pressure relief valve acts to the pressure spike.

The cut-off pressure must be set at least 725psi (50 bar) lower than the setting of the high pressure relief valves.

The allowable setting range of the cut-off pressure is from 4350psi (300 bar) to 6525psi (450 bar).

### 2-1 Specifications

### Charge Pump

Charge flow is required on all K8V pumps applied in closed-loop systems. The charge pump supplies flow to replenish, cool and filter oil, provide charge pressure and servo pressure, and flow for system control and auxiliary functions.

An integrated charge pump is available. The available charge pump sizes are as follows;

K8V90: 1.22in³ (20 cm³)/rev K8V125: 1.70in³ (28 cm³)/rev

Pressure and flow for charge circuit can be supplied by an external auxiliary pump.

An auxiliary pump for charge circuit can also be mounted on the back of the main pump using a through drive mounting.

In case the auxiliary pump is used for charge circuit, connect the charge pump delivery line to port C so that the flow is provided to the low pressure line and servo line. The integrated low pressure relief valve can be used in this case. If the integrated low pressure relief valve is not used, provide an appropriate relief valve in the system.

### 2-1 Specifications

### **Filtration of Charge Pump**


Filtration of the hydraulic fluid reduces premature wear, and enhances the reliability and life of the products. To ensure the cleanliness of the working fluid it is essential to optimize function of the machine, and extend the service life.


### Filtration system

### 1) External Filtration System/External Supply (Code: X)

This option is for a pump without an integrated charge pump. External charge pump supply comes from port C.

Filter arrangement should be made separately.






### 2) Remote Filtration System (Code: B)

This is for a pump equipped with an integrated charge pump and ports for external charge circuit filter. The filter will be located in the discharge (pressure) line of the charge pump, as shown in the hydraulic circuit below.

Filters with bypass are not recommended.

Filter arrangement must be made separately, as the filter is not included.

Charge pressure outlet: Port F<sub>1</sub> Charge pressure inlet: Port F<sub>2</sub>



### 2-2 Functional Description of Regulator

### Electric Proportional Control (Code: P1, P2)


Pump delivery flow can be proportionally controlled by the input current to the electric proportional reducing valve equipped on the regulator.


The input current of the electric proportional reducing valve signals the control spool in the regulator to stroke, and to supply pressure to the servo piston. The pump displacement varies with the stroke of the servo piston.

The feedback lever, connected with to servo piston at one end, moves with the stroke of the servo piston. This movement causes the sleeve of the control spool which is connected to the other end of the feedback lever to stroke, and closes the flow passage to the servo piston.


Consequently, the stroke of the servo piston stops, and the pump displacement becomes proportional to the input current.

#### **Control Characteristics**





### Electrical Specifications



#### **Connector Type**

Deutsch, DT04-2P

Rated Current and Coil Resistance

For 24 V supply: 0.7 A, 15  $\Omega$  (at 20°C) For 12 V supply: 1.6 A, 33  $\Omega$  (at 20°C)


Recommended dither condition 85 Hz, 200 mAp-p for 24 V

85 Hz, 600 mAp-p for 12 V

### (Note)

Electric displacement control regulator requires the minimum servo pressure as follows.

For K8V125: 290psi (20 bar) For K8V90: 363psi (25 bar)



The above figures are the control characteristics of electric proportional control. The control characteristics of electric proportional control is not adjustable.

### 2-2 Functional Description of Regulator


### Hydraulic Pilot Displacement Control (Code: P3)

Pump delivery flow can be proportionally controlled by an external pilot pressure.


The external pilot pressure signals the control spool in the regulator to stroke, and to supply pressure to the servo piston. The pump displacement varies with the stroke of the servo piston.

The feedback lever, connected to the servo piston at one end, moves with the stroke of the servo piston. This movement causes the sleeve of the control spool which is connected with the other end of the feedback lever to stroke, and closes the flow passage to the servo piston.

Consequently, the stroke of the servo piston stops, and the pump displacement becomes proportional to the external pilot pressure.



#### **Control Characteristics**



The above figure are the standard control characteristic of hydraulic pilot displacement control. If non standard control characteristics is required, please contact Kawasaki.

### 2-2 Functional Description of Regulator

### Mechanical Stroke Limiter

By an adjusting screw the maximum displacement can be adjusted infinitely to the required displacement setting. This option is under development. For details contact Kawasaki.


### Stroking Speed Control Orifice

Pump stroking speed (response) can be adjusted by changing the control orifice which is integrated in the servo line. The available control orifices and those response (for reference) are shown in the table below.

The typical orifice size used is as below;

K8V90: **Φ**1.2 K8V125: **Φ**1.0

	Codo [0]	Orifice Size	Strokin	ng Time
	Code [9]	Office Size	Neutral to Max.	Max. to Neutral
	В	Ф1.0	2.0 ~ 2.5 sec	
K8V90	С	Ф1.2	1.5 ~ 2.0 sec	0.5 ~ 1.5 sec
	D	Ф1.4	1.0 ~ 1.5 sec	
	А	Ф0.8	4.0 ~ 5.0 sec	
K8V125	В	Ф1.0	3.0 ~ 4.0 sec	0.5 ~ 1.5 sec
	С	Ф1.2	2.0 ~ 3.0 sec	




## 3 Dimensions

### **3-1 Installation Dimensions**

\* Dimensions in mm.

### • K8V90



(Note) See port details for thread size on port A1 and A2.

### **3-1 Installation Dimensions**

### • K8V90 Port Details

### Main Flanged Ports

Des	Port Name	Port Size	Flange Thread
Unified Thread	Version		
A <sub>1</sub> , A <sub>2</sub>	Pressure Port	SAE J518C high pressure (code 62) 1"	7/16-14UNC-2B-17-21.5
Metric Thread	Version		
A <sub>1</sub> , A <sub>2</sub>	Pressure Port	SAE J518C high pressure (code 62) 1"	M12-17

### **Auxiliary Ports**

Des	Port name	Port size
Dr <sub>1</sub> , Dr <sub>2</sub>	Drain Port	1-1/16-2 UN-2B-19 (ISO 11926-1)
a <sub>1</sub> , a <sub>2</sub> , a <sub>3</sub> , a <sub>4</sub>	Gauge Port	9/16-18 UNF-2B-12.7 (ISO 11926-1)
В	Inlet Port	1-5/16-12 UN-2B-19 (ISO 11926-1)
a <sub>5</sub>	Gauge Port	7/8-14 UNF-2B-16.7
a	Air Vent Port	9/16-18 UNF-2B-12.7
F <sub>1</sub>	External Filter Port (OUT)	7/8-14 UNF-2B-16.7
F <sub>2</sub>	External Filter Port (IN)	7/8-14 UNF-2B-16.7
С	External Charge Pressure Supply Port	7/8-14 UNF-2B-16.7


### 3. Dimensions

### **3-1 Installation Dimensions**


\* Dimensions in mm.

### • K8V90 Through Drive Options

### Through Drive 'A'



### Through Drive 'B'




### **3-1 Installation Dimensions**


\* Dimensions in mm.

### • K8V90 Through Drive Options

### Through Drive 'BB'



### Through Drive 'C'




### 3. Dimensions

### **3-1 Installation Dimensions**


\* Dimensions in mm.

### • K8V90 Through Drive Options

### Through Drive 'CC'




#### Through Drive 'D'



### **3-1 Installation Dimensions**

\* Dimensions in mm.

### • K8V125



(Note) See port details for thread size on port A1 and A2.


### 3. Dimensions

### **3-1 Installation Dimensions**


\* Dimensions in mm.

### • K8V125 Mounting Flange and Shaft Options

### SAE D Spline shaft



### SAE F Spline shaft



### **3-1 Installation Dimensions**

\* Dimensions in mm.

### • K8V125 Port Details

### Main Flanged Ports

Des	Port Name	Port Name Port Size						
Unified Thread Version								
A <sub>1</sub> , A <sub>2</sub>	Pressure Port	1/2-13UNC-2B-19/24						
Metric Thread Version								
A <sub>1</sub> , A <sub>2</sub>	Pressure Port	SAE J518C high pressure (code 62) 1-1/4"	M14-19					

### **Auxiliary Ports**

Des	Port name	Port size
Dr <sub>1</sub> , Dr <sub>2</sub>	Drain Port	1-1/16-2 UN-2B-19 (ISO 11926-1)
a <sub>1</sub> , a <sub>2</sub> , a <sub>3</sub> , a <sub>4</sub>	Gauge Port	9/16-18 UNF-2B-12.7 (ISO 11926-1)
В	Inlet Port	1-5/8-12 UN-2B-24 (ISO 11926-1)
a <sub>5</sub>	Gauge Port	7/8-14 UNF-2B-16.7
a	Air Vent Port	9/16-18 UNF-2B-12.7
F <sub>1</sub>	External Filter Port (OUT)	7/8-14 UNF-2B-16.7
F <sub>2</sub>	External Filter Port (IN)	7/8-14 UNF-2B-16.7
С	External Charge Pressure Supply Port	7/8-14 UNF-2B-16.7


### 3. Dimensions

### **3-1 Installation Dimensions**


\* Dimensions in mm.

### • K8V125 Through Drive Options

### Through Drive 'A'




### Through Drive 'B'




### **3-1 Installation Dimensions**

### • K8V125 Through Drive Options

### Through Drive 'BB'



### Through Drive 'C'




### **3-1 Installation Dimensions**


\*Dimensions in mm.

### • K8V125 Through Drive Options

### Through Drive 'CC'



### Through Drive 'D'



### **3-2 Installation of Auxiliary Pumps**

#### • Allowable Mass Moment for Combination Pump


K8V series allows combination of multiple pumps using through drive mounting. The second pump can be attached up to the same size of the first pump. In case of tandem configuration with the same pump size the allowable maximum dynamic acceleration to the pump is 10G. No additional mounting support is necessary up to this condition.

4-bolt mounting is required in case of tandem pumps. If the third pump has to be mounted on the back of the second pump, the pump mass moment at the mounting flange shall be within the rated mass moment. Please contact Kawasaki for details.

#### Total Length of Tandem unit

- /	1	-	:+.	:	1	m))	
- (		111	П.	111	([])	IIIIII	

First Dump	Second Pump					
First Pump	K8V90	K8V125				
K8V90	26.5 (672.5)	-				
K8V125	27.5 (698.5)	28.5 (724.5)				



Please complete the table to specify the requirements. Please contact Kawasaki for any questions.

Request Volume

Request Delivery Date

K8V seri	es Ir	nqui	ry F	orm	1											Powe	ring y		otentia
Please tick the b			•					Date:						Machin	ie Model:				
Options with 🛨	are unde	er devel	opmen	t.				Appli	cation:										
Swash Plate Typ	e Axial	Piston	Pump					Custo	mer Nan	ne:				Pump N	Model:				
Madal Cada	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17	18
Model Code	K8V		А						-										
	Items				Лodel de Pos.					Req	uirement	ts					Kawasa	ki feed b	ack
					2	90													
Pump Size (cm³)						125													
Model Code					3	A :	Series /	4											
Direction of Rotat	ion				4		Clockw												
						L :	Counte	rclockwi	ise (K8V	90)									
Manustin a Flance	I Cl 6				_		SAE - D												
Mounting Flange	and Shari	τ			5	D2 :	SAE - D	Mount	& SAE - F	Shaft (	15T-8/16	DP) (for	K8V125)						
						A1 :	SAE-A,	2 bolt, T	hrough I	Orive (9	Г-16/32D	P)							
						B1 :	SAE-B,		hrough [										
					6		SAE-BE												
Through Drive				C1 :		SAE-C,	2/4 bolt	, Througl	h Drive	14T-12/2	24DP)								
					l	SAE-CC													
					SAE-D,														
						l	Withou												
Thread Type (Suction/Delivery)							Metric												
					7	в:	Metric	Flange, N	Metric Th	readed					□ ★	-			
						l	UNF Fla												
							20 cm3												
Charge Pump					8	в:	28 cm3	(for K8	V125)										
						l	Withou												
							Ф0.8												
						l	Ф1.0												
Stroking Speed Co	ontrol Ori	fice			9	с :	Ф1.2												
					D :	Ф1.4													
						х :	Without	Orifice	Available (	Only with	Code X of	Low Pres	sure Relie	f Valve [16	5] 🗆				
					A :	With M	echanica	al Stroke	Limiter					□ *	,				
Mechanical Stroke Limiter			10	х :	Withou	t Mecha	nical Str	oke Limi	ter										
			Commi	ents (Oth	or requi	irements)						Opera	ting con	dition D	uty cycle	atc (Des	cribe voi	ır detail)	
				. ,=	- TI-	,						. , ,	J	. ,, 2 '	, ,,=	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		,	

Note

### **K8V** series Inquiry Form

Kawasaki Powering your potential

Please tick the box for options.

Options with ★ are under development.

Date: Machine Model:

Application:

Customer Name: Pump Model:

#### Swash Plate Type Axial Piston Pump


	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17	18
Model Code	K8V		А						-										

Items	Model Code Pos.	Requirements		Kawasaki feed back
Filtration System (In case the code "X" is selected in the section 8 (code for charge pump: "without	11	A : Integral Pressure Filtration  B : Remote Pressure Filtration With Ports For External Charge Circuit Filtration		
charge pump"), the code "X" (without filter) must be selected in the section 11.)		X : Without Pressure Filtration		
Swivel Angle Sensor	12	A : With Swivel Angle Sensor	□ ★	
Swiver Alligie Serisor	12	X : Without Swivel Angle Sensor		
Special Features	13	A : A $\sim$ Code Corresponding to the Feature will be set up When Necessar		
,	13	X : Without Any Special Feature		
		P1 : Electronic Proportional Displacement Control (24V)		
Control Options	14	P2 : Electronic Proportional Displacement Control (12V)		
		P3 : Hydraulic Proportional Displacement Control		
		A : 30 MPa		
		B : 35 MPa		
High Pressure Relief Valve	15	C : 40 MPa		
		D : 45 MPa		
		S : Customized Pressure Setting for Special Case		
		A : 30 MPa		
		B : 35 MPa		
Pressure Cut-Off Valve	16	C : 40 MPa		
		S : Customized Pressure Setting for Special Case		
		X : Without Pressure Cut-Off Valve		
		B : 2.5 MPa		
Low Pressure Relief Valve	17	S : Customized Pressure Setting for Special Case		
		X : Without Low Pressure Valve		
Design Code	18	** : 0.1~		

Operating condition, Duty cycle etc. (Describe your detail)

Request Volume	Request Delivery Date	Note

### **MEMO**



#### Kawasaki Precision Machinery (U.S.A.), Inc.

3838 Broadmoor Avenue S.E. Grand Rapids, Michigan 49512, U.S.A. Phone +1-616-975-3100 Fax. +1-616-975-3103 http://www.kpm-usa.com

#### **OVERSEAS SUBSIDIARIES**

#### Kawasaki Heavy Industries, Ltd.

#### **Precision Machinery Company**

http://www.khi.co.jp/kpm/

#### Tokyo Head Office

1-14-5 Kaigan, Minato-ku, Tokyo 105-8315, Japan Phone +81-3-3435-6862 Fax. +81-3-3435-2023

#### **Kobe Head Office**

Kobe Crystal Tower, 1-3 Higashikawasaki-cho 1-chome, Chuo-ku, Kobe 650-8680, Japan

Phone +81-78-360-8607 Fax. +81-78-360-8609

#### Nishi-kobe Works

234, Matsumoto, Hasetani-cho, Nishi-ku, Kobe 651-2239, Japan Phone +81-78-991-1160 Fax. +81-78-991-3186

#### Kawasaki Precision Machinery (UK) Ltd.

Ernesettle Lane, Ernesettle, Plymouth, Devon, PL5 2SA United Kingdom Phone +44-1752-364394 Fax. +44-1752-364816 http://www.kpm-eu.com

### Kawasaki Precision Machinery (Suzhou) Ltd.

668 JianLin Rd, New District, Suzhou, 215151 China Phone +86-512-6616-0365 Fax. +86-512-6616-0366

#### Kawasaki Precision Machinery Trading (Shanghai) Co., Ltd.

17th Floor (Room 1701), The Headquarters Building, No168, XiZang Road (M), Huangpu District, Shanghai, 200001, China Phone +86-21-3366-3800 Fax. +86-21-3366-3808

#### Kawasaki Chunhui Precision Machinery (Zhejiang) Ltd.

No.200 Yasha Road Shangyu Economic Development Zone, Shansyu, Zhejiang, 312300, China

Phone +86-575-8215-6999 Fax. +86-575-8215-8699

### Flutek, Ltd.

98 GIL 6, Gongdan-Ro, Seongsan-Ku, Changwon-Si, Kyungnam, 51567, Korea Phone +82-55-210-5900 Fax. +82-55-286-5557

#### Wipro Kawasaki Precision Machinery Private Limited

No. 15, Sy. No. 35 & 37, Kumbalgodu Industrial Area, Kumbalgodu Village, Kengeri Hobli, Bangalore, – 560074 ,India



QR code
Precision Machinery
Company Website